

Ballast Weights for RS-80K to RS-200K

Towing Dynamometer



Water Ballast Weights

- Weight specific to drawbar requirement
- Fully baffled
- Ballast tanks are safely secured to the trailer
- Easy to fill with water and easy to drain
- Ballast weights are fully adjustable
- Fill from any hydrant
- Easy to transport empty ballast weights
- Never a need to store heavy ballast weights
- No heavy equipment needed to load or unload empty weights
- · Sight tube for water level

Concrete Ballast Weights

- · Weight specific to drawbar requirement
- Steel encased concrete boxes; customer fills boxes
- Ballast boxes are safely secured to the trailer
- Easy to remove and load using lifting fixture
- Uniquely designed for maximum traction





Everything you need to succeed

